

**WAC 296-301-125 Ironer.** Each flat-work or collar ironer must be equipped with a safety bar or other guard across the entire front of the feed or first pressure rolls, so arranged that the striking of the bar or guard by the hand of the operator or other person will stop the machine. The pressure rolls must be covered or guarded so that the operator or other person cannot reach into the rolls without removing the guard. This may be either a vertical guard on all sides or a complete cover. If a vertical guard is used, the distance from the floor or working platform to the top of guard must not be less than 6 feet.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-301-125, filed 9/5/17, effective 10/6/17; Order 74-19, § 296-301-125, filed 5/6/74.]