

WAC 296-150C-0840 Live loads. (1) The design live loads must be established according to this chapter and must be considered to be uniformly distributed.

(2) The roof live load must not be considered as acting simultaneously with the wind load. The roof and the floor live loads must not be considered as resisting the overturning moment due to wind. The roof live load and the floor live load must be considered to act both simultaneously and separately in order to determine the critical design loading for stresses and deflections.

[Statutory Authority: RCW 43.22.340, [43.22.]355, [43.22.]360, [43.22.]432, [43.22.]440 and [43.22.]480. WSR 96-21-146, § 296-150C-0840, filed 10/23/96, effective 11/25/96.]