

**WAC 296-301-175 Hand bailing machine.** An angle-iron-handle stop guard must be installed at the right angle to the frame of the machine. The stop guard must be so designed and so located that it will prevent the handle from traveling beyond the vertical position should the handle slip from the operator's hand when the pawl has been released from the teeth of the takeup gear.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-301-175, filed 9/5/17, effective 10/6/17; Order 74-19, § 296-301-175, filed 5/6/74.]